Baby Monitor

Touch Screen

Complete operating instructions.

IMPORTANT: Keep instructions for future reference

12732

TABLE OF CONTENTS

Introduction 3
Radio Interference Advise 3
Package Contents 4
Monitor/*Receiver* 4
Camera/*Transmitter* 5
To Start
Charging/Powering On 6
Locking the Screen 6
Set to Another Language 6
Pairing Camera and Monitor 7
Main Menu 8
Touch Navigation
Volume/Display 9
Lullabys 9
Night Light 9
Record 10
Play 11
Quad and Channel View 12
VOX (Voice Activation) 12
Settings
Monitor Settings 13
Camera Settings 17
Per Camera and Convenience Icons 18
WebCam Use 19
Data/File Transfers 19
Audio/Video Out 20
Troubleshooting 20
Factory Default Settings 21
Battery Replacement 22
Product Safety 22
Focusing Camera Lens 23
Proper Disposal 23

INTRODUCTION

Congratulations on the purchase of this Touch Control Monitor, which incorporates the latest advanced technology. To fully maximize and benefit from this product's avanced features we hightly recommend you review these instructions. This 2.4 GHz Digital monitor enables you to transmit picture and sound signals cordlessly, which is ideal for many situations suchs as monitoring a baby, young children or the elderly or used as office or warehouse monitoring system.

IMPORTANT: Use ONLY a fingertip or other NON-SHARP object to select touch screen options. Using sharp objects can damage the screen and void the warranty.

RADIO INTERFERENCE ADVISE

This equipment has been tested and found to comply with the requirements of the R&TTE Directive 1995/5/EC. These requirements are designed to provide reasonable protection against harmful interference in a residential instalation. If this equipment is not installed and use in accordance with the instructions , it may cause harmful interference to radio comunications.

To correct this you should:
- Reorient or relocate the receiving antenna.
- Increase the separation between the affected equipment and the Touch Monitor.
- Connect the equipment into an outlet on a mains circuit different from that to which the receiver is connected.

In order to maintain compliance with R&TTE Directive 1995/5/CE, special shielded cables are used within this equipment. Operation with nonapproved equipment or unshielded cables is likely to result in interference to radio or TV reception. You are advised that changes and modifications not carried out on the equipment by the Molto technical service will not be covered by the product guarantee.

DECLARATION OF CONFORMITY
Hereby, Moltó y Cía, S.A. declares that this baby monitor with camera is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/CE. (more info ***www.molto.com***)

PACKAGE CONTENTS

- 1 Monitor/Receiver
- 1 Camera/Transmitter
- 2 AC/DC Adaptors 5V 800mAh
- 1 Li-Ion Rechargeable Battery(for monitor only)
- 1 Attachable Strap Mount
- 1 Door/Drawer Attachable Hook
- 1 User Manual

MONITOR

Monitor / Receiver Unit features

- 3.5” QVGA resolution TFT touch panel screen
- VGA resolution (640*480) up to 25 frames per second
- up to 250-300m range
- 2-way communication
- MENU/ESCAPE button
- PAIR Button
- TALK Button
- Lock Screen Button for disabling touch screen
- SD Card Slot up to 32 Gb (not included)
- Mini USB Output port (for connection to a PC and charging)
- A/V Output port
- DC Input (AC/DC adaptor included)
- Two-Color LED: solid green for power on; flashing red for charging
- Quad-View split screen (up to 4 camera capability)
- Main Menu color icon display
- Rechargeable Li-ion Battery 3.7V 1200 mAh (included for monitor only)

Camera / Transmitter Unit features:

- PAIR Button
- LED for Power ON / Pairing (flashes)
- Microphone & Speaker
- DC Input (AC/DC adaptor included)
- Night Vision
- Temperature Sensor and Alarm
- VOX (Hi/Mid/Lo/Off) with receiver control
- Adjustable Volume from receiver
- Adjustable TX Power (High-Low) from receiver
- 4 Lullaby choices
- Night Light
- Rechargeable Battery 3.7V 1500 mAh (not included - sold separately)
- 2.4GHz Digital FHSS, 100% secure with full privacy and interference free

POSITIONING / MOUNTING OPTIONS:

A. Horizontal to Slightly Angled Surfaces - Built-in Ridge-Grip Feet…

B. Wall Mount…

C. Door or Drawer Hook Mount / Stand (included)…

D. Horizontal Rails / Drawer Handles - Attachable Strap Mount (included)

WARNING: To prevent strangulation never place a power cord within reach of a child.

A. Plug one of the AC/DC adapters (they are interchangeable) into the monitor and allow it to **charge the Monitor Battery** for at least 6 hours.

B. Plug the other AC/DC adapter into the camera. **Turn the Camera On** by holding the **ON/OFF Button** down for several seconds. The green “Power On” Indicator lights when powered up.

C. **Turn the Monitor On** by holding its **ON/OFF Button** down for several seconds. Its “Power On” Indicator will light up (green on battery power, red when charging) and the MOLTO logo will appear on the screen.

D. **Press ESC Button** to go to the **Main Menu**.

NOTE: While viewing the Main Menu, if no buttons are pressed, or the screen is not touched after 30 seconds, the monitor will automatically exit the Main Menu mode.

Main Menu

E. **Press ESC Button** once again to go to the **Camera View**. Along the top and bottom of the screen, small “Per Camera” Icons (ex-plained on page 18) will appear over the view from the camera, which should be on and paired with the monitor.

IMPORTANT: ***Use ONLY a finger-tip or other NON-SHARP object to select touch screen options. Using sharp objects can damage the screen and void the warranty.***



Camera View

LOCKING THE SCREEN: If you press the **Lock Screen Button** a LOCK icon will appear and the touch-screen function will be disabled. Pressing the Lock Screen Button again will revert it back to normal touch-screen function.

TO SET TO ANOTHER LANGUAGE: The monitor is set to ***English*** by default. The text can also be displayed in ***French, German, Portuguese, Spanish, or Italian***. To change the language follow this sequence:

press the **ESC Button**
touch **Setting** icon
touch **System Setting**
touch slider to **See More List**
select **Language** from the list
select a new **Language**
press the **ESC Button**

PAIRING: The monitor and camera are paired (wirelessly linked) by the manufacturer at the factory. If you ever need to relink the camera, or you want to pair Additional Cameras (sold separately) you need to pair each following this sequence:

NOTE: Before pairing be sure the camera and monitor are both turned on and both are within 10 feet of each other.



1. **Power On** the Monitor and Camera

2. Press and hold the **Pair Button** on the back of the **Monitor** until the Pair Screen is displayed, then release the button.

3. Press and release the **Pair Button** on the **Monitor** and select a camera number (1-4) to be paired. The word "**Pairing**" appears below the icon of the selected camera as it waits to be paired.

4. You have 10 seconds to press and hold the Pair Button on the back of the **Camera** to complete Pairing, otherwise restart from step 2 above.

5. The word "**OK**" or "**Failed**" will be displayed on screen.

6. Press the **ESC Button** or the **Return** icon to go back. To pair additional cameras repeat the steps above.

IMPORTANT: Use ONLY a fingertip or other NON-SHARP object to select touch screen options. Using sharp objects can damage the screen and void the warranty.

Touch the appropriate icon to access all Settings and Options.

VOLUME / DISPLAY
adjust
- Sound Volume
- Screen Contrast
- Screen Brightness

LULLABYS
select
- Camera Number
- Lullaby Choice
- Lullaby Volume

NIGHT LIGHT
select
- Camera Number
- Night Light On
- Night Light Off

RECORD
select
- Record Video
- Take Photo
- Format SD Card
- SD Information
- Time/Date Stamp

PLAY
adjust/play
- Recorded Video
- Recorded Photo
- Delete Files

QUAD / CHANNEL
select
- Quad View
- Specific CAMs
- Switch CAMs

VOX (Voice Activation)
select
- Camera Number
- VOX On/Off
- Sound Sensitivity
- Auto Record On/Off

SETTINGS
for the ***Camera***
- Temperature Alarm
- TX Power/Volume

SETTINGS
for the ***Monitor***
- USB Output
- Recording Schedule
- Zoom/Pan/Tilt
- Screen Timeout
- Touch Calibration
- SD Card Update
- 6 Languages
- Reset to Default
- About / Version
- Date/Time
- Time Alarm
- Auto Switch Time
- AV Out Format

*from **Main Menu...*** *... to **These Screens...*** *... to **Do This...***

VOLUME / DISPLAY

touch – or + icons to adjust...

- ***Monitor Volume***
- ***Screen Contrast***
- ***Screen Brightness***

LULLABYS



- *select a **Camera**...*



- *select one of four **Lullabys** and/or...*
- *deactivate all **Lullabys**...*
- *adjust **Lullaby Volume***

NIGHT LIGHT

*select **Night Light** icon for the camera you wish to control in order to...*

- *turn the **Night Light ON***
- *turn the **Night Light OFF***

(the light bulb image in the icon changes to yellow when ON and back again when OFF)

*HINT: To move back one screen touch **Return** icon or go to camera view by pressing the **ESC Button**.*

*from **Main Menu...*** *... to **These Screens...*** *... to **Do This...***

RECORD



touch one of four functions...

Photo

- *goes to camera view and you can **take a photo** of the scene by touching this **Still Camera** icon*



NOTE: All recording functions require an SD memory card with available space (max 32 Gb) to be in the SD card slot on the monitor.

NOTE: Touch Date Time Stamp to activate the Date/Time Stamp to be displayed on the screen.

NOTE: While recording no other functions are available until recording is stopped.

Video

- *goes to the camera view and you can **record a video** (with sound) of the scene by touching this **REC** icon to start recording - and press again to stop recording*



SD Format

- *lets you **Format / Erase** an SD memory card*



- *select **OK** or **Cancel***

SD Info

- *displays **Total Size, Used Space,** and **Free Space** on any SD card you may have in the SD card slot*

*HINT: To move back one screen touch **Return** icon or go to camera view by pressing the **ESC Button**.*

*from **Main Menu...*** *... to **These Screens...*** *... to **Do This...***

PLAY



touch to select one of two options...

Video or Picture

*select **Video** or **Picture***

*select a folder for the **Date of the Recording** (year/month/day)*



*select a **Video** or **Picture File** to **Play** or **View***

*as you view a **Recorded Video** file the screen will also show...*

- ***Return** icon (upper left) - used to exit the playback at any time*
- ***Elapsed Time / Total Play Time** / and **File name**(upper right)*
- ***Video Play** controls (bottom center)*
- ***Delete** icon (bottom right)*

*when the **Delete** icon is touched you see this to confirm file deletion with an **OK***

*HINT: To move back one screen touch **Return** icon or go to camera view by pressing the **ESC Button**.*

*from **Main Menu...*** *... to **These Screens...*** *... to **Do This...***

QUAD / CHANNEL

*NOTE: All cameras must be **Paired** to the monitor for viewing access (Refer to Pairing on page 7.)*

*NOTE: In **Quad** mode, touching any active camera image changes to that full screen single camera view. Also sound only from the last camera in full screen mode can be monitored.*

*NOTE: In **Auto Scan** mode (indicated by this symbol) you can select which cameras to include and the scan time between each camera. (Refer to Auto Switch Time on page 13.)*



choose from these options...

Single Camera View

*select a **Camera** icon (1-4, which will be shown in color and active if paired)to be your constant channel if choosing **Single Camera View***

Quad View

*select the **Quad** icon and see all currently paired cameras (up to 4) simultaneously.*

Auto Scan View

*select the **Auto Scan** icon to go to a full view from each paired camera (up to 4) as they change from one to the next*

VOX

Sound Activated Monitoring

*NOTE: **VOX** keeps monitor (picture and sound) off until the camera detects a sound, which automatically turns the monitor back on. This helps prevent false alarms and allows parents more rest.*



Sound Activated Mode

(VOX)

*select a paired **Camera** icon (the ones in color)*

select from 3 options...

***VOX** (set to On or Off)*

***Sound Sensitivity** (set to High, Med or Low)*

***Sound-Activated Recording** (set to Yes or No)*

*HINT: To move back one screen touch **Return** icon or go to camera view by pressing the **ESC Button**.*

from ***Main Menu...*** *... to* ***These Screens...*** *... to* ***Do This...***

SETTINGS



Monitor Settings

- *on the Setting Screen, simply touch the* ***System Setting*** *icon (at the top) to access monitor functions...*



From ***the Monitor Setting list...***

- *select* ***Date/Time***
- *touch* ***any value****, then touch the* ***arrows*** *to adjust* ***value up*** *or* ***down***
- *press* ***OK*** *to save changes*

From ***the Monitor Setting list...***

- *touch* ***Time Alarm***
- *touch* ***any value****, then touch the arrows to adjust* ***value up*** *or* ***down***
- *touch* ***Alarm On*** *or* ***Alarm Off***
- *touch* ***OK to set***



From ***the Monitor Setting list...***

- *touch* ***Auto Switch Time***
- *select a* ***camera switching*** *interval (5 sec to 60 sec)*
- *check the* ***cameras*** *to be included in* ***auto switching*** *mode*
- *touch* ***OK to set***

HINT: To move back one screen touch ***Return*** *icon or go to camera view by pressing the* ***ESC Button****.*

from ***Main Menu...*** *... to* ***These Screens...*** *... to* ***Do This...***

SETTINGS *(cont.)*



Monitor Settings

From *the Monitor Setting list...*

- *select* ***TV Out Format***
- *choose either* ***PAL*** *or* ***NTSC*** *video format (EU standard is PAL)*
- *touch* ***OK to set***



From *the Monitor Setting list...*

- *select* ***Recording Schedule***
- *touch* ***any value*** *and then touch the* ***up*** *and* ***down arrows*** *to* ***adjust time***
- *to activate press* ***On*** *(or* ***OFF*** *to deactivate)*



From *the Monitor Setting list...*

- *select* ***Zoom/Pan/Tilt*** *and go to the camera scene with Zoom/Pan/Tilt icons overlaying the image...*
- *to* ***Zoom-In*** *touch the + icon (maximum of 3.0-to-1 enlargement)*
- *to* ***Zoom-Out*** *touch the – icon*
- *to* ***Pan or Tilt*** *touch the* ***arrow*** *icons (you can Pan or Tilt only after you have zoomed in)*

NOTE: Press the ESC Button to return to the video image without Zoom/Pan/Tilt icons overlaying it.

HINT: To move back one screen touch ***Return*** *icon or go to camera view by pressing the* ***ESC Button****.*

*from **Main Menu...*** *... to **These Screens...*** *... to **Do This...***

SETTINGS *(cont.)*



Monitor Settings

From *the Monitor Setting list...*

- *touch **Video Off Timeout***
- *touch the **timer** icon to choose between **non-active** (X) or **active** (no X) **Timeout Mode***
- *if active, touch the **–** or **+** icons to set the limit at which time the video will automatically **Timeout** (turn off)*



From *the Monitor Setting list...*

- *select **Touch Calibration***
- *touch the **+** icons as they appear in each corner of the screen (this calibrates the monitor for best touch screen accuracy)*
- *once all four corners are touched, tap **EXIT** to return to the Monitor Setting list*



**See page 19 for details on using the USB Output for viewing video or transferring video or photo files to a PC.*

From *the Monitor Setting list...*

- *touch **USB Output***
- *select the **Top** icon for **Charging** the monitor via the AC Adapter (included)*
- *select the **Middle** icon to use the system as a **USB Webcam** on a PC* via a USB Data Cable (not included) or...*
- *select the **bottom** icon for PC file transfer mode to or from an SD Card in the monitor via a USB Data Cable (not included)*
- *touch **OK to set***

*HINT: To move back one screen touch **Return** icon or go to camera view by pressing the **ESC Button**.*

from ***Main Menu...*** *... to* ***These Screens...*** *... to* ***Do This...***

SETTINGS *(cont.)*

Monitor Settings

From *the Monitor Setting list...*

*NOTE: Though shown here for reference, this function to be used **ONLY** for **Updating System Firmware**, to be downloaded and put onto an SD card, in order to be installed using this option. Specific instructions will be provided to registered users regarding any new firmware.*



From *the Monitor Setting list...*

- *touch **Language***
- *touch one of the 6 specific **Languages** you want the monitor to show in all text displays*



From *the Monitor Setting list...*

- *touch **Factory Default***
- *choose **OK** to **reset all settings**, or **Cancel** if you **change your mind***



From *the Monitor Setting list...*

- *touch **About & Version***
- *here you will see the product name and manufacturer, and the latest version of the installed firmware*

*HINT: To move back one screen touch **Return** icon or go to camera view by pressing the **ESC Button**.*

from ***Main Menu...*** *... to* ***These Screens...*** *... to* ***Do This...***

SETTINGS *(cont.)*



Camera Settings

- *on the Setting Screen, simply touch the* ***Camera*** *icon (on the bottom line) for the one you wish to control the settings for...*

  NOTE: Only ***Paired*** *camera icons will show in color and be active for touch control.*

From ***the Camera Setting Screen...***

- *touch* ***Temperature/Alarm***
- *set for* ***°F*** *or* ***°C*** *(default is °C)*
- *touch the* ***thermometer*** *icon*
- ***set*** *the maximum and minimum alarm* ***temperature range***
- *set the* ***Alarm*** *to be* ***On*** *or* ***Off***
- *if* ***On****, set the interval between beeps (from 5 to 60 seconds)*

NOTE: When the room ***temperature*** *(where the camera is) goes above or below the temperature range you set, the monitor will sound an alarm and the small Temperature icon on the monitor screen will flash showing the out-of-range temperature in that room. Alarm will not stop until the temperature returns to the set range, or you turn the* ***Alarm Off*** *from this screen.*



From ***the Camera Setting Screen...***

- *touch* ***Tx Power/Volume***
- *adjust the* ***Camera Speaker Volume*** *(top icon) up or down for the Two-Way Talk function*
- *set the* ***Transmit Range Power*** *(lower icon) on* ***High or Low***

HINT: To move back one screen touch ***Return*** *icon or go to camera view by pressing the* ***ESC Button****.*

IMPORTANT: Use ONLY a fingertip or other NON-SHARP object to select touch screen options. Using sharp objects can damage the screen and void the warranty.

*Specific small icons are created for each paired camera at the top edge of the screen which relate to that individual camera (except **Battery Level**, which is for the **monitor only**). To use them...*

*just observe or touch one of the following **Individual Camera** icons to either...*

A... *view **current Camera Number**, or change to the **next camera** you want to view*

B... *view **current VOX level**, or change **VOX sound sensitivity level** for that camera*

C... *view **Lullaby status**, change the **Lullaby selection**, or **turn off Lullabys** from that camera*

D... *add **Zoom/Pan/Tilt** controls over the scene to manipulate the image from that camera*

*NOTE: Other individual camera icons appear for informational purposes, such as **Room Temperature, Switching Mode** and **Signal Strength**, and when in **Quad Mode**, each camera screen shown will also display the Signal Strength of that particular camera.*



*Each paired camera scene also displays **Convenience Icons** (shown along the bottom of the screen) so you can either view the **current Date/Time Stamp or**...*

*touch and **bypass** the **Main Menu** to...*

1... *instantly adjust **Volume** controls for that camera*

2... *instantly access the **Play Video/View Photo** control panel*

3... *instantly **Record Video** from that camera...**with just one touch!***

WEBCAM USE

To view a larger version of the monitor screen on your PC screen...*

Note: Using this feature allows viewing only on the computer. Once USB Connection is established the monitor screen is turned off and all features and buttons (with the exception of the ESC Button) will not be functional.

1. *set the USB Output on the monitor to the Webcam icon (refer to page 15)*

2. *using a USB Cord (not included), connect the monitor to an available USB port on your PC**

3. *wait for your computer to automatically recognize and install the appropriate drivers and you receive a Successful Installation message.*

4. *once you have installed the device driver, your Molto Baby Monitor can be utilized as a wireless webcam.*

5. *once the picture from the monitor is displayed on your computer screen, pressing the ESC Button on the monitor toggles between Single and Quad View modes.*

The Monitor can be used in conjunction with Skype®, Windows Messenger®, Google Talk® and Yahoo Messenger®. When utilizing Skype®, Windows Messenger®, Google Talk® or Yahoo Messenger®, please refer to their documentation for techical support.

** The Monitor is only compatable with Windows® PCs.*

DATA/FILE TRANSFERS

To transfer photo and video files from the monitor to your PC ...*

Note: Using this feature allows viewing only on the computer. Once USB Connection is established the monitor screen is turned off and all features and buttons (with the exception of the ESC Button) will not be functional.

1. *set the USB Output on the monitor to the USB Connection icon (refer to page 15)*

2. *using a USB Cord (not included), connect the monitor to an available USB port on your PC**

3. *wait for your computer to automatically recognize and show the outside Memory Device.*

4. *you may then move or copy files from the SD Card (not included) as you normally would with any such storage device (provided one is in the monitor and has data stored on it)*

** The Monitor is only compatable with Windows® PCs.*

AUDIO/VIDEO OUT

You can hear and see audio/video output on a TV or other AV device directly from your Monitor.

Simply connect the AV Out Cord (not included) to the AV OUT jack on the right side of the monitor and connect the other ends (three RCA connectors) to the Audio and Video Input jacks on your TV, DVR, or Camcorder, and select the appropriate input setting on that AV device.

The monitor screen will automatically turn off, signaling the unit is connected. Please refer to your AV device manual for proper input selection and operation.

TROUBLESHOOTING

Problem	Solution
Monitor will not turn on	• Check AC/DC connection • Confirm power outlet is working properly • Charge Battery Pack
Monitor on but no picture	• Confirm “Audio Only” mode is not selected • Confirm “VOX” mode is OFF • Confirm there are no obstructions in front of camera
Camera will not turn on	• Check AC/DC connection • Confirm power outlet is working properly
Battery does not recharge	• Check AC/DC connection. • Check battery pack connection in the monitor. • Confirm power outlet is working properly • Confirm batteries are placed correctly in monitor
Connection is lost	• Confirm monitor and camera are ON. • Confirm AC/DC adapter is connected properly • Confirm battery has sufficiant power. • Place camera and monitor near each other and press camera Pair button to relink camera and monitor. • Reduce distance between camera and monitor. • Remove or avoid other wireless products that may be near camera or monitor.

Item	Default value	Range
Monitor Value Settings		
Volume	5	0-9
Contrast	5	0-9
Brightless	5	0-9
Date & Time	2011/09/01,08:00	
Alarm Time	Off, 09:00	On , Off
Date Time Stamp	Off	On , Off
Auto Switch Time	5s	5s,10s,30s,1min
Recording Schedule	Off	On , Off
	Start Time : 12:00:00	
	End Time: 12:11:00	
Zoom	1.0	1.0 a 3.0
TV Out Format	PAL	PAL,NTSC
Monitor Video Off Timeout	60s, Off	From 5s to 180s
USB Output	5V DC Input	DC Input/webcam/USB
Language	English	ENG, FR, DE, POR, ES, IT
Camera Settings Value		
VOX Settings	Off	High, Middle, Low, Off
Lullaby	Off	Off, Lull 1, Lull 2, Lull 3, Lull 4
Temperature Settings	ºC	ºC, ºF
	Max 30º - Min 15ºC	10ºC-50ºC
	Alarm Off	On , Off
	Beeps every 5”	5s, 10s, 30s, 1 min
Volume	5	0-9
TX Power	High	High, Low
Night Light	Off	Off, On

BATTERY REPLACEMENT

Monitor Battery (included)
Li-Ion 3,7V 1200 mAh

Camera Battery(not included, sold separately)
Li-Ion 3,7V 1500 mAh

PRODUCT SAFETY

•This product is not intended to be used as a medical monitor and its use should not replace adult supervision.

CAUTION
This product should not replace adult supervision.

• Periodically examine this product for damage to the cord, housing or other parts that may result in the risk of fire, electric shock or injury. Do not operate any product with a damaged cord or plug. If the Color Wireless Monitor malfunctions, or is damaged in any manner, please contact the manufacturer for examination and repair to avoid a hazard.
• Never use the Camera and/or the Monitor near water (i.e. bathtub, sink, etc.).
• The AC adapters are not toys.

WARNING
To prevent strangulation with power cord, never place transmitter within reach of child.

• Always use the Camera and the Monitor where there is adequate ventilation. To prevent overheating keep the Camera and the Monitor away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
• Use only a dry cotton cloth to keep the units free of dust. Do not use a damp cloth, water, or liquid cleaner of any kind.

CAUTION
To prevent electric shock, do not inmerse in water; wipe clean with damp cloth.

• Remove the batteries from the Monitor during long periods of non-use, as batteries can leak.
• Unplug the AC adapters from the Monitor and the Camera during periods of non-use. To disconnect from the power supply, grip the transformer and pull from the power socket. Never pull by the cord.
• Only use the Monitoring System with the supplied power adapters.

CAMERA FOCUS ADJUSTMENT INSTRUCTIONS

Occasionally you may need to adjust the camera lens for best focus.

Note: The camera lens will only turn less than 45 degrees in either direction.
Avoid any forceful turns which could damage the camera and possibly void the warranty.

1. Have the monitor turned on and near the camera you want to adjust.
2. With the camera on, place and point it to the area it will be monitoring.
3. While viewing the camera image on the monitor, grip the silver ring around the camera lens (and the LEDs around it), and then slowly and gently turn the ring.
4. When the video picture on the monitor is at the sharpest release the focus ring and leave it set at that position.

PROPER DISPOSAL

If you eventually dispose of the Monitor, Camera, Batteries, or AC Adapters, do so in accordance with current state and local regulations. As a consumer, you may be obligated by law to recycle used batteries.
Do not mix products bearing the RAEE symbol (crossed out trash bin icon) with your general household waste.
For the correct collection and treatment of these products take them to the collection points designated by your local authority. Alternatively, contact the supplier that sold you the product.

Notes:

© 2013 MOLTO - MODELO REGISTRADO

MADE IN CHINA - FABRICADO EN CHINA - FABRIQUE EN CHINE

DESIGNED AND MANUFACTURED BY - DISEÑADO Y FABRICADO POR - CONÇU ET FABRIQUÉ PAR

MOLTO Y CIA, S.A. - N.R.I. 03-10142

Avda. Azorín, 18-P.O. Box nº 49 - 03440 IBI (ALICANTE) SPAIN.

CE 1313

SD is a trademark of SD Association.
Skype®, Windows Messenger®, Google Talk®
and Yahoo Messenger® are trademarks
of their respective companies.

www.molto.com

Cod. 0671273203